

DRIVE-THRU TIMER T2

Installation Instructions



This timer is designed specifically for McDonald's(R) "30 Second" Service Guarantee promotions, and its operation is dictated by McDonald's Corp. For information regarding internal operational procedures concerning this product, please contact McDonald's Corp. directly.

Follow the 4 steps below to install this device.

1. Find a place to mount the timer on the inside surface of a window in your presenter booth.

The timer can be mounted in direct sunlight and/or on a movable window (with appropriate cable slack and ties).

Note: The unit should be located approx. 18" above the drive-thru window sill. Glass should be clean and dry. Mounting the timer as near as possible to your P.O.S. serve button will aid your crew in pressing both serve buttons quickly. Use the window frame to level the unit before mounting. Adhere the timer to the window by pressing firmly.

CAUTION: Do not mount the unit behind tinted window film, the display will not be visible to the customers. Remove any tinted film first.

2. Connect the Printer Trigger to the timer.

Follow the instructions included with the Printer Trigger to connect. Either connector on the timer may be used, they are identical.


NOTE: Wireless systems do not need any connection. Proceed to step 3.

A wireless system can be identified by the presence of short black antennas on the timer and Printer Trigger.

3. Connect the Remote Display to the timer.

Use the 25 ft. Cable included to connect and power the Remote Display. The Remote Display should be mounted in the kitchen or service area. Extension cables/couplers are available, please call to order. Commercially available telephone-type extension cords will NOT work.


NOTE: No power adapter is required for the Remote Display. It is powered by the timer.



4. Connect the Power Adapter.

Plug the power adapter into the round jack on the bottom of the timer. Insert the adapter into any wall outlet. Use ONLY the 12VDC power adapter included.

PLEASE CONSULT THE INSTRUCTION CARD FOR OPERATING INSTRUCTIONS. POST THE CARD IN YOUR DRIVE-THRU TO ASSIST CREW.



FOR SERVICE OR ASSISTANCE PLEASE CALL:

KERNELECTRONICS INC.

4246-91A Street
Edmonton, AB, CANADA T6E 5V2 **1-888-920-1234**

CAUTION:

Please call for additional cables or adapters. Telephone type extension cables will NOT work.